

AIR LUMBAR

FEATURES

- Inflatable Air Lumbar support
- Level of support is easily adjustable
- Supports your lower back
- Helps relieve lower back pain
- Available on most Office Chairs
-

INSTRUCTIONS

- Squeeze Rubber Bulb (as pictured) repeatedly to inflate Air Lumbar. The bladder is situated under the foam in the lower section of the backrest.
- Inflate to desired size.
- To deflate, press the valve located close to where the Air Lumbar is attached to the seat. Deflate to desired size.
- The Air Lumbar can be inflated and deflated as many times as required.



AIR LUMBAR

for relief from lower back pain

Inflatable Lumbar Support
Allows you to adjust your back comfort,
which can help
in the relief of lower back pain

ARTEIL
Office and Healthcare Seating Specialists

Unit 2-5
95 Garling St
O'Connor WA 6163

Tel: (08) 9337 8399
Fax: (08) 9314 1553

Email: sales@arteil.com.au
www.arteil.com.au

AIR LUMBAR