

MECHANISMS - Tiltamatic

TILTAMATIC

LEVER A - Forward Seat Tilt

- Turn lever clockwise when Lever B is in the Up position. This allows the seat to tilt forward.
- Push Lever B down to lock seat angle.

LEVER B - Seat tilt and Free floating

- Lift lever to dis-engage seat tilt lock. The chair can be tilted and used in the free float mode.
- Seat angle can be locked on and desired angle by pushing lever down

LEVER C - Seat Height

- To increase seat height, lift Lever C when not seated.
- To lower seat height lift Lever C when seated.

LEVER D - Back Angle Adjustment

- Lift to adjust back angle while seated. Push lever down when desired back angle is achieved.



ARTEIL

Office and Healthcare Seating Specialists

Unit 2-5
95 Garling St
O'Connor WA 6163

Tel: (08) 9337 8399

Fax: (08) 9314 1553

Email: sales@arteil.com.au

www.arteil.com.au